



## DESCRIPTION OF PARTS

### KIT components




- 1** Control board ZLX24S (801QA-0060 / 801QA-0080)
- 2** Control board holder
- 3** Terminal block with fuse compartment
- 4** Fuse 4 A (line 120 V)
- 5** Fuse 3.15 A (line 230 V)
- 6** Two 2-pole terminal blocks





## Description of control board components



- 1 Accessories fuse
  - 2 Control board fuse
  - 3 Terminal board for power supply to the control board
  - 4 Terminal board for connecting the signalling devices
  - 5 Terminal board for connecting control devices
  - 6 Display
  - 7 Terminal board for connecting the safety devices
  - 8 Memory Roll card connector
  - 9 Terminal board for B1-B2 output
  - 10 Connector for CAME KEY\*
  - 11 RIO CONN card connector\*
  - 12 Terminal board for CRP connection\*\*
  - 13 RSE card connector\*\*
  - 14 Terminal board for connecting the antenna
  - 15 Connector for plug-in radio frequency card (AF)
- ⚠ Use only AF43S or AF868 with diagram number DIS29101 or above.
- 16 Programming buttons
  - 17 Terminal board for BUS devices\*
  - 18 Terminal boards for connecting micro limit switches and/or encoders
  - 19 Terminal board for connecting the gearmotor with encoder or with slowdown switch and electric lock
- (\*) Cannot be used  
 (\*\*) Not suitable for spare part ZL19N

## INSTALLATION

- A** Control board support fixing point
- B** Fuse holder terminal block fixing point
-  Screws not provided. Reuse the screws in the ZL19N or ZLJ24 control panel.



## ELECTRICAL CONNECTIONS


- ⚠ Before working on the control panel, cut off the mains power supply.
- ⚠ Always insert the line fuse in the terminal block.

## ZLJ24 control panel

- ① Blue cable
- ② White cable

- ③ Red cable
- ④ Black cable


- ⑤ Orange cable
- ⑥ Purple cable



- ② White cable
- ④ Black cable

- ⑤ Orange cable
- ⑥ Purple cable

■ ■ ■ Cable not provided




## ZL19N control panel

- ① Blue cable
- ② White cable

- ③ Red cable
- ④ Black cable

- ⑤ Orange cable
- ⑥ Purple cable


- ⑦ Brown cable
- ⑧ Blue cable



- ② White cable
- ④ Black cable

- ⑤ Orange cable
- ⑥ Purple cable

■ ■ ■ Cable not provided





## Maximum capacity of contacts

 The total power of the outputs listed below must not exceed the maximum output power [Accessories]

Device	Output	Power supply (V)	Maximum power (W)
Accessories	10 - 11	26 AC	20
Additional light	10 - E3	26 AC	10
Flashing beacon	10 - E	26 AC	10
Operator status warning light	10 - 5	26 AC	3



The outputs deliver 24 V DC when the batteries start operating, if they are installed.

Device	Output	Power supply (V)	Power (W)
Auxiliary contact	B1 - B2	-	24 (24V AC/DC)

## Connecting gearmotors without R interface (control board 119RIR267)

Connection with slowdown microswitch

Connection with limit-switch/slowdown microswitch




 Set the function [F72 - Limit-switch function] taking into account the chosen connection.

## Command and control devices


### 1 STOP button (NC contact)

Stop the gate and exclude automatic closing. Use a control device to resume movement.

 When the contact is being used, it must be activated during programming.

### 2 Control device (NO contact)

OPEN ONLY function

 When the [HOLD-TO-RUN] function is active, the control device must be connected during OPENING.


### 3 Control device (NO contact)

PARTIAL OPENING or PEDESTRIAN OPENING function

 See [Adjusting partial opening] function.

### 4 Control device (NO contact)


CLOSE ONLY function

 When the [HOLD-TO-RUN] function is active, the control device must be connected during CLOSING.



### 5 Control device (NO contact)

OPEN-CLOSE function

OPEN-STOP-CLOSE-STOP function

 See control function 2-7.

### 6 Antenna with RG58 cable



## Signalling devices

### 1 Flashing beacon

It flashes when the operator opens and closes.

### 2 Additional light


It increases the light in the manoeuvring area.

 See [Additional light] function.

### 3 Operator status warning light

It notifies the user of the operator status.

 See function [Passage-open warning light].




## Safety devices

During programming, configure the type of action that must be performed by the device connected to the input.


Connect the safety devices to the CX and/or CY and/or CZ and/or CK inputs.

 If used, the contacts CX CY CZ CK must be configured during programming.

 For systems with multiple pairs of photocells, please see the manual for the relevant accessory.


### DELTA photocells

#### Standard connection




#### Connection with safety test

 See [Safety devices test] function.




## DIR / DELTA-S photocells

### Standard connection




### Connection with safety test

 See [Safety devices test] function.




DXR/DLX photocells

Standard connection




DFWN sensitive edge




Connection with safety test

See [Safety devices test] function.



## Programming button functions



### 1 ESC button

The ESC button is used to perform the operations described below.

- Exit the menu
- Delete the changes
- Go back to the previous screen
- Stop the operator

### 2 < > buttons

The < > buttons are used to perform the operations described below.

- Navigate the menu
- Increase or decrease values

### 3 ENTER button

The ENTER button is used to perform the operations described below.

- Access menus
- Confirm choice

Outside the menu, the ESC key stops the gate and the < > keys open and close the gate.

## Getting started

Once the electrical connections have been made, proceed with commissioning. Only skilled and qualified staff may perform this operation.

Please see the full control panel manual for information on the additional functions relating to the encoder, limit switch and slowdown switches.

Make sure that there are no obstacles in the way.

Power up the device and begin programming.

With mechanical and electronic stops, follow the configuration below.

## GENERIC MOTOR

Configuration>                      Motor settings>

### Motor type

Generic

### Number of motors

#### Motor test

The > button opens gate leaf M2

The < button opens gate leaf M1

 Check that both leaves open. If they do not, invert M and N on the relevant terminal.

Configuration>                      Wired safety devices>

### CX input

### CY input

### CZ input

### CK input

Configuration>                      Motor settings>

#### Limit-switch function\*

Off

 With the limit switches deactivated, the stop point is defined by mechanical stops on the ground.

Stop in FA, stop in FC

Slowdown in FA/FC (Default)

Stop in FA, slowdown in FC

#### Input type FC/FA\*

N.O. (Default)

N.C.

N.C. for FA input, N.O. for FC input

#### Motor power

Minimum power [up to 120W]

Medium power (Default) [up to 200W]

Maximum power [more than 200W]

#### Travel calibration

\*Only with end-of-travel microswitches used.

 If CALIBRATION REQUIRED appears on the display, you must calibrate the travel. The panel will not accept motion commands, except for the motor test.

 Complete programming and check the warning and safety devices are working properly.

 After powering up the system, the first manoeuvre is always to open the gate. Wait for the manoeuvre to be completed.





Press the ESC button or STOP button immediately in the event of any faults, malfunctions, strange noises or vibrations, or unexpected behaviour in the system.

## GEARMOTORS WITHOUT R INTERFACE (control board 119RIR267)

Configuration>

Motor settings>

Motor type

Generic

Number of motors

Motor test

Configuration>

Wired safety devices>

CX input

CY input

CZ input

CK input

Configuration>

Motor settings>

Limit-switch function

Slowdown in FA/FC (Default)



Select the parameter if both microswitches are used for slowdown.

Stop in FA, slowdown in FC



Select the parameter if the opening microswitch is used as a limit switch.

Input type FC/FA

N.O. (Default)



Select the parameter if both microswitches are normally open.

N.C. for FA input, N.O. for FC input

Select the parameter if the closing microswitch is normally open and the opening microswitch is normally closed.

Motor power

Minimum power [up to 120W]

Medium power (Default) [up to 200W]

Maximum power [more than 200W]

Configuration>

Gate travel settings>

Opening approach space

Closing approach space

Set a value below 5%





Slowdown AST control

Deactivated (Default)

Configuration>




Motor settings>



Travel calibration


-  If **CALIBRATION REQUIRED** appears on the display, you must calibrate the travel. The panel will not accept motion commands, except for the motor test.
-  Complete programming and check the warning and safety devices are working properly.
-  After powering up the system, the first manoeuvre is always to open the gate. Wait for the manoeuvre to be completed.
-  Press the **ESC** button or **STOP** button immediately in the event of any faults, malfunctions, strange noises or vibrations, or unexpected behaviour in the system.

## Functions menu

Configuration >	Motor settings	<b>Number of motors</b>	M1+M2 (Default) M2
Configuration >	Motor settings	<b>Motor type</b>	Generic STYLO-ME STYLO-RME FTX FAST-70 AXI AMICO FERNI FERNI-V AXO A3024N/A5024N FROG-A24 FROG-A24E (Default) ATS F1024 F4024E F4024EP
Configuration >	Motor settings	<b>Encoder</b>	Activated (Default) Off
Configuration >	Motor settings	<b>Reduce speed</b>	Deactivated (Default) 1% to 50%
Configuration >	Motor settings	<b>Limit-switch function</b>	Off Stop in FA, stop in FC Slowdown in FA/FC (Default) Stop in FA, slowdown in FC
Configuration >		<b>Input type FC/FA</b>	N.O. (Default) N.C. N.C. for FA input, N.O. for FC input
Configuration >	Motor settings	<b>Motor test</b>	The > button opens gate leaf M2 The < button opens gate leaf M1
Configuration >	Motor settings	<b>Travel calibration</b>	

Configuration >	Motor settings	<b>Motor power</b>	Minimum power [up to 120W] Medium power (Default) [up to 200W] Maximum power [more than 200W]	
Configuration >	Motor settings	<b>Configure motor M1</b>	Motor type Encoder Limit-switch function Input type FC/FA Motor power	 See the specific parameters for each function.
Configuration >	Motor settings	<b>Configure motor M2</b>	Motor type Encoder Limit-switch function Input type FC/FA Motor power	 See the specific parameters for each function.
Configuration >	Gate travel settings	<b>Opening speed</b>	40% to 100% (Default 70%)	
Configuration >	Gate travel settings	<b>Closing speed</b>	40% to 100% (Default 70%)	
Configuration >	Gate travel settings	<b>Travel AST control</b>	Deactivated (Default)  <b>Maximum thrust and low obstruction sensitivity.</b> Minimum Average Maximum* <b>(*) Minimum thrust and high obstruction sensitivity.</b>	Customised Customised closing Customised opening
Configuration >	Gate travel settings	<b>Adjusting the partial opening</b>	10% to 100% (Default 100%)	
Configuration >	Gate travel settings	<b>Opening approach space</b>	0.5% to 25.0% (Default 8.0%)	
Configuration >	Gate travel settings	<b>Closing approach space</b>	0.5% to 25.0% (Default 8.0%)	

Configuration >	Gate travel settings	<b>Opening slowdown point</b>	Deactivated (Default) 1% to 50%
Configuration >	Gate travel settings	<b>Closing slowdown point</b>	Deactivated (Default) 1% to 50%
Configuration >	Gate travel settings	<b>Opening slowdown speed</b>	10% to 50% (Default 40%)
Configuration >	Gate travel settings	<b>Closing slowdown speed</b>	10% to 50% (Default 40%)
Configuration >	Gate travel settings	<b>Slowdown AST control</b>	<div> Deactivated (Default) Customised </div> <div>  <b>Maximum thrust and low obstruction sensitivity.</b> Customised closing </div> <div> Minimum Average Maximum* Customised opening </div> <div> <b>(*) Minimum thrust and high obstruction sensitivity.</b> </div>
Configuration >	Gate travel settings	<b>Impact test</b>	Activate test mode Deactivate test mode
Configuration >	Gate travel settings	<b>Configure travel M1</b>	<div> Opening speed  Closing speed  Opening approach space  Closing approach space  Opening slowdown point  Closing slowdown point  Opening slowdown speed  Closing slowdown speed </div> <div>  <b>See the specific parameters for each function.</b> </div>

Configuration >	Gate travel settings	<b>Configure travel M2</b>	Opening speed Closing speed Opening approach space Closing approach space Opening slowdown point Closing slowdown point Opening slowdown speed Closing slowdown speed	 <b>See the specific parameters for each function.</b>
Configuration >	Wired safety devices	<b>Total stop</b>	Deactivated (Default) On	
Configuration >	Wired safety devices	<b>CX input</b> <b>CY input</b> <b>CZ input</b> <b>CK input</b>	Deactivated (Default) C1 = Reopen while closing (photocells) C2 = Reclose while opening (photocells) C3 = Partial stop Only with [Automatic close] activated. C4 = Obstacle standby (photocells) C7 = Reopen while closing (sensitive edges) C8 = Reclose while opening (sensitive edges) C13 = Reopen while closing, with immediate stop once the obstruction has been removed, even if the gate is not in motion r7 = Reopen while closing (sensitive edges with 8K2 resistor) r8 = Reclose while opening (sensitive edges with 8K2 resistor) r7 (two sensitive edges) = Reopen while closing (pair of sensitive edges with 8K2 resistor) r8 (two sensitive edges) = Reopen while closing (pair of sensitive edges with 8K2 resistor)	
Configuration >	Wired safety devices	<b>Safety devices test</b>	Deactivated (Default) CX _ _ _ _ CY _ _ CX CY _ _ _ _ CZ _ CX _ CZ _ _ CY CZ _ CX CY CZ _ _ _ _ CK	CX CY CZ _ _ _ _ CK CX _ _ CK _ CY _ CK CX CY _ CK _ _ CZ CK CX _ CZ CK _ CY CZ CK CX CY CZ CK

Configuration >	Command inputs	<b>Command 2-7</b>	Step-by-step (Default) Sequential
Configuration >	Functions	<b>Electric lock</b>	Deactivated (Default) From open From closed From open and closed Continue
Configuration >	Functions	<b>Closing thrust</b>	Deactivated (Default) Minimum Medium Maximum
Configuration >	Functions	<b>Thrust</b>	Deactivated (Default) On
Configuration >	Functions	<b>Removing obstacles</b>	Deactivated (Default) On
Configuration >	Functions	<b>B1-B2 output</b>	Bistable Monostable: on from 1 to 180 seconds (Default 1)
Configuration >	Functions	<b>Hold-to-run</b>	Deactivated (Default) On
Configuration >	Times	<b>Automatic closure</b>	Deactivated (Default) From 1 to 180 seconds
Configuration >	Times	<b>Automatic closing after either partial or pedestrian opening</b>	Off 1 to 180 seconds (Default 10)
Configuration >	Times	<b>M1 opening delay time</b>	Off 1 to 10 seconds (Default 2)
Configuration >	Times	<b>M2 closing delay time</b>	Off 1 to 25 seconds (Default 2)

Configuration >	Manage lights	<b>Passage-open warning light</b>	Warning light on (Default) - The warning light stays on when the gate is moving or open. Warning light flashing - The warning light flashes every half second when the gate is opening and stays on when the gate is open. The light flashes every second when the gate is closing, and remains off when the gate is closed.	
Configuration >	Manage lights	<b>Additional light</b>	Disabled (Default) Cycle lamp - The lamp stays on during the manoeuvre. Courtesy light - The light switches on when a manoeuvre starts and remains on once the manoeuvre has finished, for the time set under the function [Courtesy time].	
Configuration >	Manage lights	<b>Courtesy time</b>	60 to 180 seconds (Default 60 seconds)	
Configuration >	Manage lights	<b>Pre-flashing time</b>	Deactivated (Default) 1 to 10 seconds	
Configuration >	RSE communication	<b>CRP address</b>	1 to 254 (Default 1)	
Configuration >	RSE communication	<b>RSE speed</b>	4800 bps 9600 bps 14400 bps 19200 bps	38400 bps (Default) 57600 bps 115200 bps
Configuration >	External memory	<b>Save data</b>		
Configuration >	External memory	<b>Read data</b>		
Configuration		<b>Parameter reset</b>	Confirm? NO Confirm? YES	
Configuration		<b>Guided procedure (Wizard)</b>		
Manage users		<b>New user</b>	Step-by-step Sequential Open	Partial opening B1-B2 output



Manage users	<b>Remove user</b>	Use the arrows to choose the number associated with the user you want to remove. Confirm? NO Confirm? YES
Manage users	<b>Remove all</b>	Confirm? NO Confirm? YES
Manage users	<b>Radio decoding</b>	All decoding (Default) Rolling code TW Key block Confirm? NO Confirm? YES
Manage users	<b>Self-Learning Rolling</b>	Deactivated (Default) On
Manage users	<b>Change mode</b>	Step-by-step Sequential Open Partial opening B1-B2 output Confirm? NO Confirm? YES
Information	<b>FW version</b>	FW MC.x.x.xx (motor board firmware version) FW UI.x.x.xx (display board firmware version) GUI x.x (graphics)
Information	<b>Manoeuvre counter</b>	Total manoeuvres Manoeuvres performed since the operator was installed. Partial manoeuvres Manoeuvres carried out after the last maintenance.
Information	<b>Configure maintenance</b>	Deactivated (Default) 1X100 to 500X100
Information	<b>Maintenance reset</b>	Confirm? NO Confirm? YES

Information	Errors list	Confirm? NO Confirm? YES		
Timer management	Show clock			
Timer management	Set the clock	Use the arrows and the Enter button to enter the desired values.		
Timer management	Automatic DST	Deactivated (Default) On Summer changeover: +1 hour on the last Sunday in March (change to daylight saving time). Winter changeover: -1 hour on the last Sunday in October (change to standard time).		
Timer management	Time format	24-hour 12-hour		
Timer management	Create new timer	Open Partial opening B1-B2 output	Start time End time	Days of the week  Select days All week
Timer management	Remove timer	0 = [Opening] P = [Partial opening] B = [Output B1-B2]		
	Language	Italiano (IT) English (EN) (Default) Français (FR) Deutsch (DE) Español (ES) Português (PT) Русский (RU)	Polski (PL) Românesc (RO) Magyar (HU) Hrvatski (HR) Український (UA) Nederlands (NL)	
Password	Enable password	Use the arrows and the Enter button to dial the desired code.		
Password	Remove password	Confirm? NO Confirm? YES		

## Forgotten password

If you lose the password, you will need to reset the board to its factory settings. See [Factory reset].

## Factory reset

Disconnect the control board from the power supply and wait for it to switch off.

Press and hold the < and > buttons, then reconnect the control board to the power supply.


Continue to press and hold the < > buttons until [Factory reset] is displayed.

Select [Confirm YES].

Press ENTER to confirm.

**⚠ When you reset the control board, all saved users, set times, manoeuvre configurations and calibration operations are deleted.**

## Import/export data



Save user data and system configuration data on a MEMORY ROLL card.

The stored data can be reused for another control board of the same type to carry across the same configuration.

**⚠ Before inserting and removing the MEMORY ROLL card, DISCONNECT THE MAINS POWER SUPPLY TO THE LINE.**

**1** Insert the MEMORY ROLL card into the corresponding connector on the control board.

**2** Press the "Enter" button to access programming.

**3** Use the arrows to choose the desired function.

Configuration >

External memory >

**Save data**

Save user data, timings and configurations to the memory device (memory roll).

Configuration >

External memory >

**Read data**

Upload user data, timings and configurations to the memory device (memory roll).

**📖 Once the data have been saved and loaded, the MEMORY ROLL can be removed.**

## ERROR MESSAGES

<b>E1</b>	Motor M1 calibration error
<b>E2</b>	Motor M2 calibration error
<b>E3</b>	Encoder signal not detected error
<b>E4</b>	Service test failure error
<b>E7</b>	Operating time error
<b>E9</b>	Consecutive obstacles detected during closing
<b>E10</b>	Consecutive obstacles detected during opening
<b>E11</b>	Maximum number of obstacles
<b>E12</b>	Motor supply voltage missing or insufficient
<b>E13</b>	Limit switch input error or both limit switches open
<b>E15</b>	Incompatible transmitter error
<b>E17</b>	Wireless system communication error
<b>E18</b>	Wireless system not configured error
<b>E24</b>	BUS device communication error
<b>E25</b>	Address settings error on BUS devices









**CAME.COM**

**CAME S.P.A.**

Via Martiri della Libertà, 15  
31030 Dosson di Casier  
Treviso - Italy  
Tel. (+39) 0422 4940  
Fax (+39) 0422 4941  
info@came.com - www.came.com